


NUT AND BOLT[®] Storehouse

INDUSTRIAL NUT & BOLT STOREHOUSE

MODEL 927

ASSEMBLY & OPERATING INSTRUCTIONS



Due to continuing improvement, actual product may differ slightly from the product described herein.



3491 Mission Oaks Blvd., Camarillo, CA 93011
Visit our Web Site at www.harborfreight.com

Copyright[®] 2006 by Harbor Freight Tools[®]. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

For technical questions and replacement parts please call 1-800-444-3353.

THANK YOU for choosing a **HARBOR FREIGHT TOOLS** product. For future reference, please complete the owner's record below:

Model _____ **Serial No.** _____ **Purchase Date** _____

SAVE THE RECEIPT, WARRANTY AND THESE INSTRUCTIONS. It is important that you read the entire manual to become familiar with the unit BEFORE you begin assembly.

Technical Specifications

The Industrial Nut and Bolt Storehouse is organized to help you quickly find the right Nut, Bolt and Washers. Set includes forty large lift-out bins.

The Nut and Bolt Storehouse includes the following hardware:

Description	Quantity	Description	Quantity
Machine Bolt 5/16"-16" X 1	25	Nut 7/16-14	45
Machine Bolt 5/16-16" X 1-1/2"	25	Split Washer 7/16	45
Machine Bolt 5/16" X 2"	20	Flat Washer 7/16	45
Machine Bolt 5/16" X 2-1/2"	15	Machine Bolt 1/2 X 13 X 1	5
Machine Bolt 5/16" X 3	10	Machine Bolt 1/2 X 13 X 1-1/2	5
Nut 5/16-18	95	Machine Bolt 1/2 X 13 X 2	5
Split Washer 5/16"	95	Machine Bolt 1/2 X 13 X 2-1/2	5
Flat Washer 5/16"	95	Machine Bolt 1/2 X 13 X 3	5
Machine Bolt 3/8" X 16 X 1	24	Nut 1/2 X 13	25
Machine Bolt 3/8" X 16 X 1-1/2"	22	Split Washer 1/2	25
Machine Bolt 3/8" X 16" X 2"	18	Flat Washer 1/2	25
Machine Bolt 3/8" X 16" X 2-1/2"	15	Machine Bolt 5/8-11 X 1-1/2	4
Machine Bolt 3/8" X 16" X 3"	10	Machine Bolt 5/8-11 X 2	4
Nut 3/8" X 16"	90	Machine Bolt 5/8-11 X 2-1/2	4
Split Washer 3/8"	90	Machine Bolt 5/8-11 X 3	4
Flat Washer 3/8"	90	Machine Bolt 5/8-11	20
Machine Bolt 7/16" X 14 X 1"	15	Split Washer 5/8	20
Machine Bolt 7/16" X 14 X 1-1/2"	40	Flat Washer 5/8	20
Machine Bolt 7/16" X 14 X 2"	10	Mounting Rails	10
Machine Bolt 7/16" X 14 X 2-1/2	5	Bins	40
Machine Bolt 7/16" X 14 X 3"	3		



READ ALL INSTRUCTIONS BEFORE USING THIS PRODUCT!

Safety Warnings and Precautions

WARNING: When using product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment.

Read all instructions before using this product!

1. **Keep work area clean.** Cluttered areas invite injuries.

2. **Check for damaged parts.** Before using any product, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function. Check for any broken or damaged parts and any other conditions that may affect its operation. Replace or repair damaged or worn parts immediately.
3. **Replacement parts and accessories.** When servicing, use only identical replacement parts. Use of any other parts will void the warranty.
4. **Keep children away. Children must never be allowed in the work area.** The Nut and Bolt Storehouse contains nails and tacks which can be swallowed by children, and which can also cause serious injury. **Do not let children handle the Nut and Bolt Storehouse.**
5. **Dress properly.** Gloves are recommended when using nuts and bolts. Wear restrictive hair covering to contain long hair.
6. **Use eye protection.** Always wear ANSI approved impact safety goggles when assembling and using this product.
7. **Maintain product with care.** Store the Nut and Bolt Storehouse in a dry location.
8. **Do not exceed the products maximum weight capacity of 3 Lbs. for each bin.**
9. **Use the Nut and Bolt Storehouse for the appropriate situation. There are certain applications for which this Storehouse was designed. Do not modify this Nut and Bolt Storehouse and do not use this Storehouse for a purpose for which it was not intended.**

WARNING: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

Unpacking

When unpacking your Nut and Bolt Storehouse, check to make sure that it is intact and undamaged. If it is damaged or broken, please call **HARBOR FREIGHT TOOLS** at **1-800-444-3353**.

Assembly


Your Nut and Bolt Storehouse will require basic assembly. It is important that you read the entire manual to become familiar with the product BEFORE you assemble and use the Storehouse. Before assembling the Nut and Bolt Storehouse be sure that you have all parts described in the Parts List located on page 2 of this manual.

The Nut and Bolt Storehouse can be used either as a free-standing racks or it can be mounted on a wall.

Free-Standing Racks

To use the Nut and Bolt Storehouse as a free-standing rack, simply stack the Racks one on top of each other.

Note: Some parts are listed and shown for illustration purposes only and are not available individually as replacement parts.



Wall Mounting

1. To hang the Nut and Bolt Storehouse from a wall or workbench, use a level to set an even line to hang the Mounting Rails. Use a drill to set the path for each Screw. **Make certain that the drilling path of the Screw is clear and free of obstacles such as wires, cables and lines.** Use wall anchors (not included) as necessary. Insert screws through each hole in the Mounting Rail and into a stud. Make certain to insert a screw through every hole in the Mounting Rail. If not fully and adequately screwed into the stud, the Mounting Rails and Bins will pull away from the wall, damaging the Nut and Bolt Storehouse and creating a hazard.
2. Up to four Bins can be installed onto each Mounting Rail.
3. Once the Mounting Rail is fully anchored to the wall, place the tabs at the top of each Bin over the lip of the Mounting Rail as shown in Figure 1.

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER NOR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.